

LoRaSCAN-FM

2D Wireless Barcode ScannerWireless barcode scanner for
Automated Industrial applications



Key Features

- Scans many popular barcode types
- Extremely long range wireless transmission of 3km+ indoors
- 50-750mm scanning range
- 24V Powered | 24V Dry contact trigger | 24V Pulse Output
- Surface mounting brackets included, pole mount optional
- Industrial rugged design for factory environments













Datasheet Video Order

LoRaSCAN-HHR

Specification



Scanning

- Resolution: 640*480 3mil/0.1mm (PCS90%, CODE 39)
- Scanner type: CMOS
- Illumination: Red Light LED 525±10nm, 5600K LED (lighting)
- Print contrast ratio: 15%
- Scan angle: Roll ±360°, Pitch ±60°, Skew ±55°
- Scanning distance: 50mm ~ 750mm
- Manual, Autosense & Continuous scan modes

Wireless

- Very long range wireless transmission
- 8km outdoor, 3km indoor (line of sight)
- Internal antenna
- 868MHz 925MHz for worldwide usage
- Robust & secure industrial protocol
- All data encrypted as standard

Electrical

- 24VDC powered (power supply not included)
- 24V dry contact to trigger scanning
- 24V pulse output following successful scan
- Energy saving 2 minute auto shutdown
- Includes Phoenix contact connector MC 1,5/ 4-STF-3,81
- Blue LED power indicator

Physical

- IP62 rated
- 120mm x 120mm x 70mm
- -20 to +50 degrees C operating temperature range

Regulatory

- CE
- FCC
- RoHS

Ordering

LORASCAN-FM

Wireless scanner, surface mount accessories

LORASCAN-FM-STARTER

Wireless scanner, connector & USB wireless receiver dongle

- LORASCAN-USB
- USB wireless receiver dongle







Datasheet Video Order

LoRaSCAN-HHR **Installation Manual**



Safety



DANGER

Only to be installed by qualified & competent electrical engineer



CAUTION Risk of Electric shock

Important safety information is contained in this document.


Familiarise yourself with this information before attempting installation or other procedures. This product can only be installed by persons trained and competent to permanently install mains powered electrical equipment.

Please read this installation guide fully before beginning and if you have any questions contact us: Low Power Radio Solutions Ltd, Two Rivers Ind. Estate, Station Lane, Witney, OX28 4BH, UK. Tel: +44 1993 709418. Email: sales@lprs.co.uk

Connectors & Wiring


Enclosure Connector: DFK-MC 1,5/ 4-GF-3,81

Mating Connector: DFK-MC 1,5/ 4-STF-3,81









- Ground (GND) 1.
- **24 VDC (PWR)**
- 24V Read Trigger (TRIG_24V)
- Pulse output (PULSE_OUT)

* DO NOT DEVIATE FROM THE ABOVE WIRING DIAGRAM *

Instructions

- a) When wiring the mating connector shown above, ensure your power supply is switched off.
- b) Please make sure the wiring diagram is followed without deviation. Not following this diagram can lead to serious injury and/or damage to the device.
- c) Pins 3 & 4 are 24V dry contact switches. Pin 3 is for instructing the device to take a barcode reading, where idle is LOW (0V) and operate is HIGH (24V). Pin 4 is an output that will change state LOW (0V) to HIGH (24V) when a successful scan / reading has occurred.







Datasheet Video Order

LoRaSCAN-HHR Installation Manual



Safety



DANGER

Only to be installed by qualified & competent electrical engineer



CAUTIONRisk of Electric

Important safety information is contained in this document.

Familiarise yourself with this information before attempting installation or other procedures. This product can only be installed by persons trained and competent to permanently install mains powered electrical equipment.

Please read this installation guide fully before beginning and if you have any questions contact us: Low Power Radio Solutions Ltd, Two Rivers Ind. Estate, Station Lane, Witney, OX28 4BH, UK. Tel: +44 1993 709418.

Email: sales@lprs.co.uk

Mounting

This device has 3 options for mounting as shown below. The first 2 are supplied with the device with option 3 a purchasable accessory.






Wall mount with flanges





Desktop / table mount



Pole mount kit (not included)





